FOREWORD

This wiring diagram manual has been prepared to provide information on the electrical system of the DYNA 200.

Applicable models: BU300, 303, 340, 343 Series
XZU300, 320, 330, 340, 404, 412, 414, 422, 424, 434
WU300, 340, 410

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
● DYNA 200 Chassis and Body Repair Manual	RM1008E
● 14B Engine Repair Manual	RM1009E
● W04D–J Engine Repair Manual	RM1010E
● S05C–B, S05C–TA, S05C–TB Engine Repair Manual	RM1011E
● DYNA New Car Features	NCF239E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.