
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
EB1	Frame No.3 Wire and Engine Room Main Wire (Right Side of the No.3 Crossmember)
EC1	Engine No.2 Wire and Engine Room Main Wire (Left Side of the No.3 Crossmember)
EE1	Engine Room No.4 Wire and Engine Room Main Wire (Front Crossmember)
EH1	Engine Room Main Wire and Engine Wire (Upper the Alternator)