PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Magnetic Clutch (S05C–B, S05C–TA, W04D–J)	90980–11069
	A/C Magnetic Clutch (15B–FTE, S05C–TB, N04C–TF)	90980–11271
A 2	ABS Speed Sensor Front LH	90980–11073
A 3	ABS Speed Sensor Front RH	
A 4	Accel Position Sensor	90980–11930
A 6	Alternator (Except W04D–J, N04C–TF)	90980–09212
	Alternator (W04D–J, N04C–TF)	90980–09213
A 7	Alternator	90980–11349
A 8	A/C Amplifier	90980–10801
A 9	A/C SW	90980–11280
A10	A/C Thermistor	90980–10825
A11	Accelerator Pedal Position Sensor (N04C–TF)	90980–11858
	Accelerator Pedal Position Sensor (15B–FTE, S05C–TB)	90980–11232
A13	ABS Actuator (N04C–TF)	90980–11893
	ABS Actuator (S05C–TB)	90980–11413
A14	ABS Actuator	90980–11698
A15	ABS Speed Sensor Rear LH (Except GVWR 5.5t)	90980–11073
	ABS Speed Sensor Rear LH (GVWR 5.5t)	90980–11773
A16	ABS Speed Sensor Rear RH (Except GVWR 5.5t)	90980–11073
	ABS Speed Sensor Rear RH (GVWR 5.5t)	90980–11773
A17	Airbag Sensor Assembly	90980–11872
A18	Airbag Sensor Front	90980–11856
A19	Airbag Squib (Steering Wheel Pad)	90980–11884
A20	Air Flow Meter	90980–11317
B 1	Back–Up Light SW (Except N04C–TF)	90980–11250
	Back–Up Light SW (N04C–TF)	90980–11003
B 2	Brake Vacuum Warning SW	90980–11252
B 3	Blower Motor	90980–10214
B 4	Blower Resistor	90980–10171
B 5	Brake Fluid Level Warning SW	90980–10214
B 6	Brake Vacuum Warning Buzzer	90980–10825
B 7	Buckle SW (Driver's Side)	90980–11212
B 8	Brake Lock Valve	90980–10941
C 1	Camshaft Position Sensor (N04C–TF)	90980–11143
	Camshaft Position Sensor (S05C–TB)	90980–10598
C 2	Condenser Fan Motor and Resistor	90980–10841
C 3	Crankshaft Position Sensor (S05C–B, S05C–TA, N04C–TF)	90980–11162
	Crankshaft Position Sensor (S05C–TB)	90980–10598
	Crankshaft Position Sensor (W04D–J)	90980–10923
	Crankshaft Position Sensor (15B–FTE)	90980–11162
C 4	Cigarette Lighter	90980–10760
C 5	Combination Meter	90980–12169

Code	Part Name	Part Number
C 6	Combination Meter	90980–12200
C 7	Combination SW	90980–10803
C 8	Combination SW	90980–11913
C 9	Condenser Fan Fuse	90980–10214
C10	Clutch Pedal Stroke Sensor	90980–11349
D 1	Diode (A/C No.1)	90980–11608
D 2	Diode (Pressure Charge Valve)	90980–10962
D 3	DLC3	90980–11665
D 5	Door Courtesy SW (Driver's Side)	90980–10871
D 6	Door Lock Control SW	90980–11245
D 7	Door Lock Motor (Passenger's Side)	90980–11019
D 8	DC/DC Converter	90980–10997
D 9	Diode (A/C No.2)	90980–11608
D10	Diode (ES Start)	90980–10962
D11	Diode (Parking Brake) (N04C–TF)	90980–10962
	Diode (Parking Brake) (S05C–TB)	90980–11071
D12	Diode (Stop)	90980–11071
D13	Door Courtesy SW (Passenger's Side)	90980–10871
D14	Diode (Parking)	90980–11071
D15	Diode (Stop 1)	90980–11608
D16	Diode (Stop 2)	
E 1	EFI Water Temp. Sensor	90980–11451
	Water Temp. Sender	
E 2	Engine Oil Level Warning SW	90980–10532
E 3	Exhaust Brake Solenoid	90980–10923
E 4	Engine ECU (N04C–TF)	90980–12144
	Engine ECU (15B–FTE, S05C–TB)	90980–11421
E 5	Engine ECU (N04C–TF)	90980–12145
	Engine ECU (15B–FTE, S05C–TB)	90980–11476
E 6	Engine ECU (N04C–TF)	90980–12146
	Engine ECU (15B–FTE, S05C–TB)	90980–11637
E 7	Engine ECU (N04C–TF)	90980–12142
	Engine ECU (15B–FTE, S05C–TB)	90980–11638
E 8	Exhaust Brake Accelerator Pedal SW	90980–10825
E 9	Exhaust Brake Clutch SW	90980–10935
E10	EDU (N04C–TF)	90980–11592
	EDU (15B–FTE)	90980–11024
E11	EFI Water Temp. Sensor	90980–11062
E12	Engine Speed Sensor	90980–11250
E13	ES Start Main SW	90980–10908
E14	ES Start Timing SW	90980–10801
E15	ES Start ECU	90980–11424
E16	ES Start ECU	90980–11390
E17	EDU	90980–11593
E18	EGR Valve Position Sensor	90980–11317
E19	ES Start Main SW	90980–11529

Note: Not all of the above part numbers of the connector are established for the supply.

PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
E20	ES Starting System Warning Buzzer	90980–10214
F 1	Front Clearance Light LH	90980–11020
F 2	Front Clearance Light RH	
F 3	Front Fog Light LH	90980–11019
F 4	Front Fog Light RH	
F 5	Front Turn Signal Light LH	90980–11003
F 6	Front Turn Signal Light RH	
F 7	Fuel Filter Warning SW (S05C–B, S05C–TA, S05C–TB, W04D–J)	90980–10737
	Fuel Filter Warning SW (14B, 15B–FTE, N04C–TF)	90980–11003
F 8	Fuel Pressure Sensor (Except N04C–TF)	82580–6630A
	Fuel Pressure Sensor (N04C–TF)	90980–11194
F 9	Fuel Sender	90980–10834
F10	Fuel Temp. Sensor (S05C–TB)	90980–10737
	Fuel Temp. Sensor (15B–FTE, N04C–TF)	90980–11062
F11	Flasher Relay	90980–10173
F12	Front Side Turn Signal Light LH	90980–11019
F13	Front Side Turn Signal Light RH	
F15	First Gear Position SW	90980–11003
F16	Front Fog Light SW	90980–10795
G 1	GLOW MAIN Relay	99141–13006
G 2	GLOW MAIN Relay	
G 3	GLOW MAIN Relay	90980–11299
G 4	Glow Plug	–
H 1	Headlight Beam Level Control Actuator LH	90980–11016
H 2	Headlight Beam Level Control Actuator RH	
H 3	Headlight LH	90980–11314
H 4	Headlight RH	
H 6	Horn (Low)	90980–10619
H 7	Hazard SW	90980–10801
H 8	Headlight Beam Level Control SW	90980–11296
H 9	Heater Control SW	90980–10714
I 1	Injection Pump Correction Resistor	–
I 2	Injector No.1 (N04C–TF)	90980–11875
	Injector No.1 (S05C–TB)	82580–7990A
I 3	Injector No.2 (N04C–TF)	90980–11875
	Injector No.2 (S05C–TB)	82580–7990A
I 4	Injector No.3 (N04C–TF)	90980–11875
	Injector No.3 (S05C–TB)	82580–7990A
I 5	Injector No.4 (N04C–TF)	90980–11875
	Injector No.4 (S05C–TB)	82580–7990A
I 6	Ignition SW	90980–11537
I 7	Interior Light	90980–11918
I 8	Injection Pump (14B)	90980–10690
	Injection Pump (15B–FTE)	90980–11028

Code	Part Name	Part Number
I 9	Intake Air Temp. Sensor (N04C–TF)	90980–11025
	Intake Air Temp. Sensor (15B–FTE)	90980–11401
I10	Intake Heater	99141–13006
I11	Integration Relay	90980–10819
I12	ISC Valve	90980–10695
I13	Idle Variable Resistor SW	90980–10908
J 1	Junction Connector	90980–10830
J 2	Junction Connector	90980–11542
J 3	Junction Connector	
J 4	Junction Connector	
J 5	Junction Connector	
J 6	Junction Connector	
J 7	Junction Connector	90980–10803
J 8	Junction Connector (LHD, N04C–TF)	90980–10803
	Junction Connector (RHD Except N04C–TF)	90980–11542
J 9	Junction Connector	90980–10807
J10	Junction Connector	90980–11915
J11	Junction Connector	
J12	Junction Connector	90980–11542
J13	Junction Connector	90980–10803
J14	Junction Connector	90980–10807
J15	Junction Connector	90980–11542
J16	Junction Connector	90980–10803
J17	Junction Connector	90980–11542
J18	Junction Connector	90980–11915
J19	Junction Connector	90980–11542
J20	Junction Connector	
J21	Junction Connector	90980–11398
J22	Junction Connector	90980–10807
J23	Junction Connector	90980–11542
J24	Junction Connector	90980–11661
J25	Junction Connector	
J27	Junction Connector	90980–10799
J28	Junction Connector	90980–10807
J29	Junction Connector	
J30	Junction Connector	90980–11915
J31	Junction Connector	
J32	Junction Connector	90980–10803
J33	Junction Connector	90980–11542
J34	Junction Connector	90980–10803
J35	Junction Connector	
J36	Junction Connector	90980–11915
J37	Junction Connector	

Note: Not all of the above part numbers of the connector are established for the supply.

PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
J38	Junction Connector	90980–11661
J39	Junction Connector	
J40	Junction Connector	90980–10807
L 1	License Plate Light LH	90980–10498
L 2	License Plate Light RH	
M 1	Master Cylinder Pressure Sensor	90980–10845
N 1	Neutral Position SW	90980–11075
O 1	Oil Pressure SW (Except 14B)	90980–11363
	Oil Pressure SW (14B)	90980–10359
P 1	Pressure SW (Except N04C–TF)	90980–10943
	Pressure SW (N04C–TF)	90980–11149
P 2	PTO Solenoid Valve	90980–10923
P 3	PTO Transmission Neutral Position SW (Except N04C–TF)	90980–10887
	PTO Transmission Neutral Position SW (N04C–TF)	90980–11250
P 4	Power Outlet (Room)	90980–10171
P 5	PTO Clutch SW	90980–10860
P 6	PTO SW or Short Pin	90980–10997
P 7	Parking Brake SW	90980–10795
P 8	Power Outlet	90980–11178
P 9	Power Window Control SW (Passenger's Side)	90980–10631
P10	Power Window Master SW	90980–10799
P11	Power Window Motor (Driver's Side)	90980–11003
P12	Power Window Motor (Passenger's Side)	
P13	Power Steering Oil Pressure SW	90980–11428
P14	Parking Light SW or Short Pin	90980–10045
P15	Pre–Heating Timer (S05C–B)	
	Pre–Heating Timer (W04D–J)	90980–11915
P16	Pretensioner (Driver's Side)	90980–11862
R 1	Radio and Player	90980–10997
R 3	Rear Combination Light LH (Completion Vehicle)	90980–11290
	Rear Combination Light LH (Except Completion Vehicle)	90980–10173
R 4	Rear Combination Light RH (Completion Vehicle)	90980–11290
	Rear Combination Light RH (Except Completion Vehicle)	90980–10173
R 6	Reverse Warning Buzzer	90980–11156
S 1	Short Connector	82580–7980A
S 2	Short Connector	82580–8230A
S 3	Speed Sensor (Combination Meter) (Except 15B–FTE, N04C–TF)	90980–11143
	Speed Sensor (Combination Meter) (N04C–TF)	90980–11020
	Speed Sensor (Combination Meter) (15B–FTE)	90980–10981

Code	Part Name	Part Number
S 4	Starter (S05C–B, S05C–TA, S05C–TB, N04C–TF)	–
	Starter (W04D–J)	90980–09507
	Starter (14B, 15B–FTE)	90980–09508
S 5	Starter (S05C–TA, S05C–TB)	90980–11184
	Starter (W04D–J, N04C–TF)	99141–13006
	Starter (14B, 15B–FTE)	90980–11184
S 6	STARTER Relay (S05C–B, S05C–TA, W04D–J)	99141–14006
	STARTER Relay (S05C–TB, N04C–TF)	99141–13006
S 7	STARTER Relay	99141–13006
S 8	STARTER Relay	90980–11299
S 9	Suction Control Valve No.1	90980–10720
S10	Suction Control Valve No.2	
S11	Skid Control ECU (N04C–TF)	90980–11638
	Skid Control ECU (S05C–TB)	90980–11390
S12	Skid Control ECU (S05C–TB)	90980–11391
	Skid Control ECU	90980–11637
S13	Skid Control ECU (N04C–TF)	90980–11476
	Skid Control ECU (S05C–TB)	90980–11408
S14	Skid Control ECU (N04C–TF)	90980–11421
	Skid Control ECU (S05C–TB)	90980–11392
S15	Stop Light SW (Except N04C–TF)	90980–10916
	Stop Light SW (N04C–TF)	90980–11118
S16	Speaker LH	90980–10935
S17	Speaker RH	
S21	Spill Valve	90980–11155
T 1	Tilt Cab Control SW	90980–11075
T 2	Turbo Pressure Sensor (S05C–TB)	82580–6630A
	Turbo Pressure Sensor (15B–FTE, N04C–TF)	90980–10845
T 3	Tachograph	82580–7000A
T 4	Throttle Control Motor	90980–11144
T 5	Throttle Open SW	90980–11038
T 6	Timing Control Valve (LHD)	90980–11153
	Timing Control Valve (RHD)	90980–10846
T 7	Throttle Position Sensor	90980–11261
V 1	Vacuum Sensor No.1	90980–10845
V 2	Vacuum Sensor No.2	
V 3	VSV (Intake Shutter)	90980–11149
V 4	VRV (EGR)	90980–11162
V 5	VSV (EGR Cut)	90980–11156
V 6	VSV (Exhaust Brake)	
V 7	VSV (Pressure Sensor)	90980–11149
V 8	Voltage Converter	90980–12012

Note: Not all of the above part numbers of the connector are established for the supply.

PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
W 1	Water Temp. SW (S05C–B, S05C–TA, S05C–TB, W04D–J)	90980–10892
	Water Temp. SW (14B, 15B–FTE)	90980–08074
W 2	Wiper Motor	90980–11599
W 3	Washer Motor	90980–10214

Code	Part Name	Part Number
W 4	Water Temp. Sender (S05C–TA)	90980–11451
	Water Temp. Sender (14B)	90980–10359
	Water Temp. Sender (15B–FTE)	90980–11428
W 5	Water Temp. Sender	90980–11451
	Water Temp. Sensor	
W 6	Warm Up SW	90980–10799

Note: Not all of the above part numbers of the connector are established for the supply.