










FRONT SUSPENSION

PREPARATION

022DV–01

SST

	09309–60010	Extension Pipe	FRONT SPRING ASSY LH(METAL BUSH TYPE)
	09726–27012	Front Suspension Arm Bushing Remover & Replacer	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	(09726–02041)	Replacer	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	09950–40011	Puller B Set	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	(09951–04010)	Hanger 150	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	(09952–04010)	Slide Arm	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	(09953–04020)	Center Bolt 150	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	(09954–04010)	Arm 25	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	(09955–04051)	Claw No.5	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	(09957–04010)	Attachment	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	(09958–04011)	Holder	FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	09950–60010	Replacer Set	FRONT SPRING ASSY LH(METAL BUSH TYPE) FRONT SPRING ASSY LH(RUBBER BUSH TYPE)

	(09951–00300) Replacer 30	FRONT SPRING ASSY LH(METAL BUSH TYPE) FRONT SPRING ASSY LH(RUBBER BUSH TYPE)
	09950–70010 Handle Set	FRONT SPRING ASSY LH(METAL BUSH TYPE)
	(09951–07100) Handle 100	FRONT SPRING ASSY LH(METAL BUSH TYPE)

Equipment

Camber–caster–king pin gauge	
Dial indicator with magnetic base	
Drill	
Micrometer	
MP grease	
Press	
Torque wrench	
Turning radius gauge	
Vernier calipers	
Vise	