





REAR SUSPENSION

PREPARATION

022DU–01

SST

	09309–60010	Extension Pipe	REAR LH SPRING ASSY(METAL BUSH TYPE)
	09710–28012	Front Suspension Bushing Tool Set	REAR LH SPRING ASSY(RUBBER BUSH TYPE)
	(09710–07062)	Bushing Replacer	REAR LH SPRING ASSY(RUBBER BUSH TYPE)
	09710–30041	Rear Suspension Bushing Tool Set	REAR LH SPRING ASSY(RUBBER BUSH TYPE)
	(09710–03211)	Remover	REAR LH SPRING ASSY(RUBBER BUSH TYPE)
	09950–60010	Replacer Set	REAR LH SPRING ASSY(METAL BUSH TYPE) REAR LH SPRING ASSY(RUBBER BUSH TYPE)
	(09951–00300)	Replacer 30	REAR LH SPRING ASSY(METAL BUSH TYPE)
	(09951–00350)	Replacer 35	REAR LH SPRING ASSY(RUBBER BUSH TYPE)
	09950–70010	Handle Set	REAR LH SPRING ASSY(METAL BUSH TYPE) REAR LH SPRING ASSY(RUBBER BUSH TYPE)
	(09951–07100)	Handle 100	REAR LH SPRING ASSY(METAL BUSH TYPE) REAR LH SPRING ASSY(RUBBER BUSH TYPE)

Equipment

Drill	
MP grease	
Press	
Torque wrench	
Vise	