

















DIFFERENTIAL












PREPARATION








022EV–01

SST

	09223–15020	Oil Seal & Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH13)
	09223–78010	Crankshaft Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH13)
	09286–46011	Injection Pump Spline Shaft Puller	DIFFERENTIAL CARRIER ASSY REAR(B305)
	09308–10010	Oil Seal Puller	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B305)
	09315–00022	Clutch Release Bearing Remover & Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH13)
	09316–20011	Transfer Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(B265)
	09316–60011	Transmission & Transfer Bearing Replacer	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B305) DIFFERENTIAL CARRIER ASSY REAR(SH13)
	(09316–00011)	Replacer Pipe	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B305) DIFFERENTIAL CARRIER ASSY REAR(SH13)
	(09316–00041)	Replacer ”C”	REAR DIFFERENTIAL CARRIER OIL SEAL
	(09316–00071)	Replacer ”F”	DIFFERENTIAL CARRIER ASSY REAR(SH13)
	09330–00021	Companion Flange Holding Tool	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)

	09504–00011	Differential Side Bearing Adjusting Nut Wrench	DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305) DIFFERENTIAL CARRIER ASSY REAR(SH13)
	09506–35010	Differential Drive Pinion Rear Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(B265)
	09518–36020	Rear Axle Hub Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH13)
	09527–17011	Rear Axle Shaft Bearing Remover	DIFFERENTIAL CARRIER ASSY REAR(B305)
	09608–32010	Steering Knuckle Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY REAR(B305)
	09710–22021	Front Suspension Bushing Tool Set	DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09710–01051)	Lower Arm Bushing Remover	DIFFERENTIAL CARRIER ASSY REAR(B305)
	09950–00020	Bearing Remover	DIFFERENTIAL CARRIER ASSY REAR(B305) DIFFERENTIAL CARRIER ASSY REAR(SH13)
	09950–00030	Bearing Remover Attachment	DIFFERENTIAL CARRIER ASSY REAR(SH13)
	09950–30012	Puller A Set	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09951–03010)	Upper Plate	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09953–03010)	Center Bolt	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)

	(09954–03010) Arm	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09955–03030) Lower Plate 130	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09956–03040) Adapter 22	DIFFERENTIAL CARRIER ASSY REAR(B265)
	(09956–03050) Adapter 24	REAR DIFFERENTIAL CARRIER OIL SEAL DIFFERENTIAL CARRIER ASSY REAR(B305)
	09950–40011 Puller B Set	DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09951–04010) Hanger 150	DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09951–04020) Hanger 200	DIFFERENTIAL CARRIER ASSY REAR(B265)
	(09952–04010) Slide Arm	DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09953–04020) Center Bolt 150	DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09953–04030) Center Bolt 200	DIFFERENTIAL CARRIER ASSY REAR(B265)
	(09954–04010) Arm 25	DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09955–04061) Claw No.6	DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09957–04010) Attachment	DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)

	(09958–04011)	Holder	DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	09950–60010	Replacer Set	DIFFERENTIAL CARRIER ASSY REAR(B265) DIFFERENTIAL CARRIER ASSY REAR(B305)
	(09951–00480)	Replacer 48	DIFFERENTIAL CARRIER ASSY REAR(B265)
	(09951–00500)	Replacer 50	DIFFERENTIAL CARRIER ASSY REAR(B265)
	(09951–00560)	Replacer 56	DIFFERENTIAL CARRIER ASSY REAR(B305)
	09950–60020	Replacer Set No.2	DIFFERENTIAL CARRIER ASSY REAR(B265)
	(09951–00780)	Replacer 78	DIFFERENTIAL CARRIER ASSY REAR(B265)
	(09951–01030)	Replacer 103	DIFFERENTIAL CARRIER ASSY REAR(B265)
	09950–70010	Handle Set	DIFFERENTIAL CARRIER ASSY REAR(B265)
	(09951–07150)	Handle 150	DIFFERENTIAL CARRIER ASSY REAR(B265)

Equipment

Dial indicator with magnetic base	
Press	
Snap ring expander	
Torque wrench	
Vise	