


















DRIVE SHAFT / PROPELLER SHAFT











PREPARATION





022EW–01

SST


	09214–76011	Crankshaft Pulley Replacer	REAR AXLE HUB LH(5 HUB BOLTS) REAR AXLE HUB LH(6 HUB BOLTS)
	09308–00010	Oil Seal Puller	REAR AXLE HUB LH(5 HUB BOLTS) REAR AXLE SHAFT(5 HUB BOLTS) FRONT AXLE HUB SUB–ASSY LH(5–BOLTS DRUM BRAKE) REAR AXLE SHAFT(6 HUB BOLTS) FRONT AXLE HUB SUB–ASSY LH(6–BOLTS DRUM BRAKE) PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE) FRONT AXLE HUB SUB–ASSY LH(DISC BRAKE)
	09309–37010	Transmission Bearing Replacer	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	09316–60011	Transmission & Transfer Bearing Replacer	FRONT AXLE HUB SUB–ASSY LH(5–BOLTS DRUM BRAKE) PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	(09316–00011)	Replacer Pipe	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	09325–20010	Transmission Oil Plug	PROPELLER INTERMEDIATE SHAFT ASSY(LE–TYPE)
	09330–00021	Companion Flange Holding Tool	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	09332–25010	Propeller Shaft Center Bearing Replacer	PROPELLER SHAFT ASSY(B–TYPE) PROPELLER SHAFT ASSY(LE–TYPE) PROPELLER INTERMEDIATE SHAFT ASSY(LE–TYPE)
	09510–36010	Rear Hub & Drum Puller	REAR AXLE HUB LH(5 HUB BOLTS) FRONT AXLE HUB SUB–ASSY LH(6–BOLTS DRUM BRAKE) FRONT AXLE HUB SUB–ASSY LH(DISC BRAKE)
	09513–36020	Rear Axle Bearing Lock Nut Wrench	REAR AXLE HUB LH(5 HUB BOLTS)

	09513–36030	Rear axle Bearing Lock Nut Wrench	REAR AXLE HUB LH(6 HUB BOLTS)
	09517–36010	Rear Axle Shaft Oil Seal Replacer–	REAR AXLE SHAFT(5 HUB BOLTS) REAR AXLE SHAFT(6 HUB BOLTS)
	09518–36020	Rear Axle Hub Oil Seal Replacer	REAR AXLE HUB LH(5 HUB BOLTS)
	09520–00031	Rear Axle Shaft Puller	REAR AXLE HUB LH(6 HUB BOLTS)
	09550–55011	Differential Replacer Set	REAR AXLE HUB LH(6 HUB BOLTS)
	09601–37011	King Pin Bushing Remover & Replacer	STEERING KNUCKLE LH(5 HUB BOLTS) STEERING KNUCKLE LH(6 HUB BOLTS)
	09710–28021	Front Suspension Bushing Tool Set	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	(09710–08031)	Base	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	09930–00010	Drive Shaft Nut Chisel	PROPELLER INTERMEDIATE SHAFT ASSY(LE–TYPE)
	09950–30012	Puller A Set	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	(09951–03010)	Upper Plate	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	(09953–03010)	Center Bolt	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	(09954–03010)	Arm	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)

	(09955–03030)	Lower Plate 130	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	(09956–03030)	Adaptor 20	PROPELLER INTERMEDIATE SHAFT ASSY(B–TYPE)
	09950–40011	Puller B Set	REAR AXLE HUB LH(6 HUB BOLTS)
	(09951–04020)	Hanger 200	REAR AXLE HUB LH(6 HUB BOLTS)
	(09952–04010)	Slide Arm	REAR AXLE HUB LH(6 HUB BOLTS)
	(09953–04020)	Center Bolt 150	REAR AXLE HUB LH(6 HUB BOLTS)
	(09954–04030)	Arm 150	REAR AXLE HUB LH(6 HUB BOLTS)
	(09955–04021)	Claw No.2	REAR AXLE HUB LH(6 HUB BOLTS)
	(09957–04010)	Attachment	REAR AXLE HUB LH(6 HUB BOLTS)
	09950–60010	Replacer Set	STEERING KNUCKLE LH(6 HUB BOLTS) REAR AXLE HUB LH(6 HUB BOLTS)
	(09951–00410)	Replacer 41	STEERING KNUCKLE LH(6 HUB BOLTS)
	(09951–00580)	Replacer 58	REAR AXLE HUB LH(6 HUB BOLTS)
	09950–60020	Replacer Set No.2	FRONT AXLE HUB SUB–ASSY LH(5–BOLTS DRUM BRAKE)

	(09951–00720) Replacer 72	FRONT AXLE HUB SUB–ASSY LH(5–BOLTS DRUM BRAKE)
	(09951–00890) Replacer 89	FRONT AXLE HUB SUB–ASSY LH(5–BOLTS DRUM BRAKE)
	(09951–01030) Replacer 103	FRONT AXLE HUB SUB–ASSY LH(5–BOLTS DRUM BRAKE)
	09950–70010 Handle Set	STEERING KNUCKLE LH(5 HUB BOLTS) REAR AXLE HUB LH(5 HUB BOLTS) FRONT AXLE HUB SUB–ASSY LH(5–BOLTS DRUM BRAKE) STEERING KNUCKLE LH(6 HUB BOLTS) REAR AXLE HUB LH(6 HUB BOLTS) FRONT AXLE HUB SUB–ASSY LH(6–BOLTS DRUM BRAKE) FRONT AXLE HUB SUB–ASSY LH(DISC BRAKE)
	(09951–07150) Handle 150	STEERING KNUCKLE LH(5 HUB BOLTS) REAR AXLE HUB LH(5 HUB BOLTS) FRONT AXLE HUB SUB–ASSY LH(5–BOLTS DRUM BRAKE) STEERING KNUCKLE LH(6 HUB BOLTS) REAR AXLE HUB LH(6 HUB BOLTS) FRONT AXLE HUB SUB–ASSY LH(6–BOLTS DRUM BRAKE) FRONT AXLE HUB SUB–ASSY LH(DISC BRAKE)
	(09951–07200) Handle 200	STEERING KNUCKLE LH(6 HUB BOLTS)
	09951–01100 Replacer 110	REAR AXLE HUB LH(5 HUB BOLTS)

Recomended Tools

	09905–00012 Snap Ring No.1 Expander	

Equipment

Chisel	
Dial indicator with magnetic base	
Feeler gauge	
Micrometer	
MP grease	

Plastic hammer	
Press	
Spring tension gauge	
Snap ring pliers	
Torque wrench	
Vise	

SSM

08833–00100	THREE BOND 1360K or equivalent	