MANUAL TRANSMISSION / TRANSAXLE

030Z8–08

TORQUE SPECIFICATION

Part Tightened	N·m	kgf·cm	ft·lbf
Filler and drain plugs	37	377	27
Engine x Transmission 14B Engine	71.5	729	53
Engine x Transmission Except 14B Engine	43	439	32
Engine rear mounting x Frame	74	755	55
Engine rear mounting x Transmission	64	650	47
Clutch release cylinder set bolt	12	122	9
Selecting bellcrank support x Transmission	36	367	27
Shift and select outer lever x Gear shifting rod	17.5	179	13
Shift and select outer lever x Shift and select transmission cable	12	122	9
Transmission control shift cable x Floor shift assy	11.5	117	8.5
Transmission control shift cable adjust lock nut	13	133	9.6
Floor shift selecting bellcrank x Floor shift lever retainer	12	120	9
Floor shift lever x Floor select lever	14.5	145	11
Floor shift control lever stopper set bolt	5	50	44 in.·lbf
Floor shift assy x Body	18	183	13
Floor shift grommet x Floor	7	71	62 in.·lbf