DTC	17	INTERIOR IC MALFUNCTION

CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
17	ECM malfunction	• ECM

INSPECTION PROCEDURE

HINT:

This code is output when a malfunction is detected inside the ECM. However, if the same code will not be output after it is deleted, this can be considered as a temporary misoperation due to interference of electrical wave. Therefore the ECM has no problem if it recovers normally.