ABS & BA SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

057EK–02

HINT:

Troubleshoot in accordance with the procedures on the following pages.

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS (See page 05–194)

3	CHECK AND CLEAR DTCs (See page 05–195)

4	PROBLEM SYMPTOM CONFIRMATION

- SYMPTOM DOES NOT OCCUR: Go to step 5
- SYMPTOM OCCURS: Go to step 6

5	SYMPTOM SIMULATION (See page 01–17)

6	DTC CHECK (See page 05–195)

- DTC IS NOT OUTPUT: Go to step 7
- DTC IS OUTPUT: Go to step 8

7	PROBLEM SYMPTOMS TABLE (See page 05–213)

- CHECK FOR FLUID LEAKAGE AND Go to step 10

8	DTC CHART (See page 05–205)

9	CIRCUIT INSPECTION (See page 05–214)

10	IDENTIFICATION OF PROBLEM

11	REPAIR

12	CONFIRMATION TEST

END

HINT:
Step 3, 6, 8, 9, 12:
Diagnostic steps require the use of the hand–held tester.
Fail–safe function:
When a failure occurs in the ABS system, the ABS warning light is lit and the ABS operation is prohibited.