057EO–03

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing the skid control ECU, sensor, etc., turn the ignition switch OFF.

Symptom	Suspected Area	See Page
* ABS does not operate	1. Check DTC reconfirming that normal code is output 2. IG power source circuit 3. Speed sensor circuit	05–195 05–236 05–214 05–219
* ABS does not operate efficiently	1. Check DTC reconfirming that the normal code is output 2. Speed sensor circuit 3. Stop lamp switch circuit	05–195 05–214 05–219 05–242
* BRAKE ASSIST	1. Master cylinder pressure sensor 2. Vacuum sensor 3. Stop lamp switch circuit	05–239 05–239 05–242
ABS warning light abnormality	1. ABS warning light circuit 2. Skid control ECU 3. Combination meter and power source	05–254 01–27 71–2
* DTC check cannot be performed	1. ABS warning light circuit 2. Tc terminal circuit	05–254 05–251 05–263
Speed sensor signal check cannot be performed	1. TS terminal circuit 2. Skid control ECU	05–265 01–27

HINT:

*: Replace the skid control ECU only when the checking circuits of each failure symptom are all normal although the failure occurs.