05BBI–01

DIAGNOSTIC TROUBLE CODE CHART

NOTICE:

Before replacing or removing the part, turn the ignition switch OFF.

DTC No. (See Page)	Detection Item	Trouble Area
2 (05–282)	Power supply harness disconnection	• Battery • Charging system • Hill holder ECU
3 (05–284)	Clutch stroke sensor system malfunction	• Clutch stroke sensor • Hill holder ECU
4 (05–287)	Vehicle speed sensor malfunction (Speedometer sensor)	• Speedometer sensor • Hill holder ECU
6	Gradient sensor malfunction (in hill holder ECU)	• Hill holder ECU
7 (05–289)	Rear ES start valve malfunction (Hill holder brake lock valve)	• Hill holder brake lock valve • Hill holder ECU
9 (05–291)	Clutch stroke sensor power supply system malfunction (Clutch stroke sensor)	• Clutch stroke sensor • Hill holder ECU
11 (05–294)	Neutral start switch system or backup light switch* system malfunction	• Neutral start switch • Back–up lamp switch • Hill holder ECU
12 (05–297)	Neutral start switch system malfunction	• Neutral start switch • Speedometer sensor • Hill holder ECU
13 (05–284)	Stop light switch malfunction (Stop lamp switch)	• Stop lamp switch • Hill holder ECU
14	Controller (thermistor) malfunction	• Hill holder ECU
16	Controller (E. PROM) malfunction	• Hill holder ECU
18 (05–302)	ES Start main switch malfunction	• ES start main switch • Hill holder ECU
19 (05–305)	Front ES start valve malfunction (Hill holder brake lock valve)	• Hill holder brake lock valve • Hill holder ECU
21 (05–307)	ES start timing switch malfunction	• ES start timing switch • Hill holder ECU

*: Back–up lamp switch