050WZ–15

# DIAGNOSTIC TROUBLE CODE CHART

| DTC No. (See Page) | Detection Item | Trouble Area | SRS Warning Light |
|---|---|---|---|
| B0100/13 (05–322) | • Short in D Squib Circuit | • Horn button assy (D squib)<br>• Spiral cable sub–assy<br>• Airbag ECU assy<br>• Wire harness | ON |
| B0101/14 (05–326) | • Open in D Squib Circuit | • Horn button assy (D squib)<br>• Spiral cable sub–assy<br>• Airbag ECU assy<br>• Wire harness | ON |
| B0102/11 (05–330) | • Short in D Squib Circuit (To Ground) | • Horn button assy (D squib)<br>• Spiral cable sub–assy<br>• Wire harness | ON |
| B0103/12 (05–334) | • Short in D Squib Circuit (To B+) | • Horn button assy (D squib)<br>• Spiral cable sub–assy<br>• Wire harness | ON |
| B0130/63 (05–338) | • Short in P/T Squib (RH) Circuit | • Seat belt pretensioner RH (P/T squib)<br>• Airbag ECU assy<br>• Wire harness | Blink |
| B0131/64 (05–342) | • Open in P/T Squib (RH) Circuit | • Seat belt pretensioner RH (P/T squib)<br>• Airbag ECU assy<br>• Wire harness | Blink |
| B0132/61 (05–346) | • Short in P/T Squib (RH) Circuit (To Ground) | • Seat belt pretensioner RH (P/T squib)<br>• Airbag ECU assy<br>• Wire harness | Blink |
| B0133/62 (05–350) | • Short in P/T Squib (RH) Circuit (To B+) | • Seat belt pretensioner RH (P/T squib)<br>• Airbag ECU assy<br>• Wire harness | Blink |
| B1100/31 (05–354) | • Airbag ECU Assy Malfunction | • Airbag ECU assy | ON |
| B1135/24 (05–356) | • Harf Connection in Airbag ECU Assy Connector | • Electrical connection check mechanism<br>• Airbag ECU assy | ON |
| B1148/36 (05–358) | • Short in Airbag Sensor Assy No. 2 Circuit (To B+) | • Airbag sensor assy No. 2<br>• Cowl wire | ON |
| Normal (05–362) | • System Normal | – | OFF |
| | • Source Voltage Drop | • Battery<br>• Airbag ECU assy | ON |

HINT:

- When the SRS warning light remains lit on and the DTC is the normal code, this means that the power source voltage drops.
  If no malfunction code is stored in the memory of the airbag ECU assy and if the power source voltage returns to normal, the SRS warning light will automatically go off.
- When 2 or more codes are indicated, the codes are displayed in numeral order starting from the lowest numbered code.
- If the code that is not listed on the chart is displayed, the airbag ECU assy is faulty.