050YH–16

PROBLEM SYMPTOMS TABLE

HINT:

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspected Area	See Page
• When ignition switch is in ACC or ON position, SRS warning light sometimes lights up after approx. 6 seconds have elapsed	• SRS warning light circuit malfunction (Remains on when ignition switch is in LOCK position).	05–365
• SRS warningremains on even when ignition switch is in the LOCK position		
• With ignition switch is in ACC or ON position, SRS warning light does not light up	• SRS warning light circuit malfunction (Does not light up when ignition switch is turned to ACC or ON).	05–369
• No DTC is displayed	• Tc terminal circuit	05–371
• SRS warning light remains on during DTC check procedures		
• DTC is displayed without TC and CG terminals connection		