054EM–02

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Pressing power switch does not start system.	1. Radio receiver assy power source circuit 2. Radio receiver assy	05–381
Turning on light switch does not light up night time illumination of radio receiver.	1. Radio receiver assy ILL terminal circuit 2. Radio receiver assy	05–384
No sound is heard from speaker in all modes.	1. Speaker circuit 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–386
Sound quality is bad in all modes (Volume is too low).	1. Speaker circuit 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–389
Radio broadcast cannot be received (Bad reception).	1. Antenna circuit 2. Radio receiver assy	05–392
Noise occurs.	–	05–394
Cassette tape cannot be inserted or played.	1. Cassette tape 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–395
Cassette tape cannot be ejected.	1. Cassette tape 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–399
Sound quality is bad only when playing tape (Volume is too low).	1. Cassette tape 2. Radio receiver assy	05–401
Tape is tangled due to incorrect tape speed or auto–reverse malfunction.	1. Cassette tape 2. Radio receiver assy	05–402
CD cannot be inserted or is ejected right after insertion.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–403
Although system is powered, CD cannot be played.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–406
CD cannot be taken out.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–409
Sound quality is bad only when CD is played (Volume is too low).	1. CD	–
CD sound skips.	1. CD 2. Radio receiver assy installation	05–412