SOUND QUALITY IS BAD ONLY WHEN CD IS PLAYED (VOLUME IS TOO LOW)

INSPECTION PROCEDURE

1	REPLACE CD WITH ANOTHER AND RECHECK

(a) Replace the faulty CD with the normal one in order to see if the same trouble occurs again.
Standard: Malfunction disappears.

OK → **CD FAULTY**

NG

REPAIR OR REPLACE DISC PLAYER ASSY