110QD–01

REPLACEMENT

1. WORK FOR PREVENTING GASOLINE FROM SPILLING OUT
2. DISCONNECT BATTERY NEGATIVE TERMINAL
3. DRAIN FUEL
4. DISCONNECT FUEL SENDER GAUGE CONNECTOR
5. DISCONNECT FUEL MAIN TUBE
6. DISCONNECT FUEL RETURN TUBE
7. DISCONNECT CHECK VALVE FUEL HOSE
8. REMOVE FUEL TANK ASSY
(a) Take out the fuel tank band, and then remove the fuel tank.
9. REMOVE FUEL SENDER GAUGE ASSY
(a) Remove the 5 screws and fuel sender gauge from the fuel tank.
10. REMOVE FUEL TANK VENT TUBE SUB–ASSY
(a) Remove the 6 bolts and fuel tank vent tube.
11. REMOVE FUEL VAPOR SEPARATE VALVE
(a) Remove the 2 bolts and fuel vapor separate valve.
12. INSTALL FUEL VAPOR SEPARATE VALVE
(a) Install the fuel vapor separate valve with the 2 bolts.
13. INSTALL FUEL TANK VENT TUBE SUB–ASSY
(a) With a new gasket, install the fuel tank bent tube with the bolts.
14. INSTALL FUEL SENDER GAUGE ASSY
(a) With a new gasket, install the fuel sender gauge with the 5 screws.
Torque: 1.5 N·m (15 kgf·cm, 13 in.·lbf)
15. INSTALL FUEL TANK ASSY
(a) Install the tank and fuel tank band.
Torque: 13 N·m (132 kgf·cm, 10 ft·lbf)
16. CONNECT CHECK VALVE FUEL HOSE
17. CONNECT FUEL RETURN TUBE
18. CONNECT FUEL RETURN TUBE
19. CONNECT FUEL SENDER GAUGE CONNECTOR
20. ADD FUEL
21. CONNECT BATTERY NEGATIVE TERMINAL
22. BLEED FUEL
23. INSPECT FOR FUEL LEAKS