FUEL SYSTEM (W04D–J)

110QP–01

ON–VEHICLE INSPECTION

1. CHECK FUEL LEAK

(a) Check that there are no leaks from any part of the fuel system when the engine stops.

If there is fuel leakage, replace those parts.

(b) While cranking or starting the engine, check that there are no leaks from any part of the fuel system.

If there is fuel leakage, replace those parts.

(c) Disconnect the return hose from the injection pump.

(d) While cranking the engine, check fuel leakage from the return pipe.

(e) Check that there are no leaks from any part of the fuel system.

NOTICE:

If the leakage from the return pipe is less than 10 cc (0.6 cu in.) in a minute, it is acceptable.