OIL FILTER SUB–ASSY (14B)

170ED–01

REPLACEMENT

CAUTION:

- **Prolonged and repeated contact with mineral oil will result in the removal of natural fats from the skin, leading to dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contaminants which may cause skin cancer.**
- **Exercise caution in order to minimize the length and frequency of contact of your skin to used oil. Wear protective clothing and gloves. Wash your skin thoroughly with soap and water, or use water–less hand cleaner to remove any used engine oil. Do not use gasoline, thinners, or solvents.**
- **In order to preserve the environment, used oil and used oil filter must be disposed of only at designated disposal sites.**


1. DRAIN ENGINE OIL

(a) Remove the oil filler cap.

(b) Remove the oil drain plug, and drain the oil into a container.

2. REMOVE OIL FILTER SUB–ASSY

SST 09228–44011



3. INSTALL OIL FILTER SUB–ASSY

(a) Using SST, remove the oil filter.
SST 09228–44011

(b) Check and clean the oil filter installation surface.

(c) Apply clean engine oil to the rubber gasket of a new oil filter.

(d) Lightly screw the oil filter into place, and tighten it by hand until the rubber gasket contacts the installation surface.

(e) Using SST, tighten the oil filter by an additional 3/4 turn to seat the filter.

4. ADD ENGINE OIL

(a) Clean the drain plug, and install a new gasket and the drain plug.
Torque: 35 N·m (360 kgf·cm, 26 ft·lbf)

(b) Add fresh engine oil.
Oil capacity:

Drain and refill	w/ oil filter change	9.3 liters (9.8 US qts, 8.2 Imp. qts)
	w/o oil filter change	8.4 liters (8.9 US qts, 7.4 imp. qts)
Dry fill		10 liters (10.6 US qts, 8.8 Imp. qts)

(c) Reinstall the oil filler cap.

5. CHECK ENGINE OIL LEVEL

6. CHECK FOR ENGINE OIL LEAKS