320TS–01

REPLACEMENT

1. **REMOVE INSTRUMENT PANEL ASSY (See page 71–11, 71–17)**
2. **REMOVE BRAKE MASTER LESS RESERVOIR TANK CYLINDER SUB–ASSY (See page 32–10)**
3. **REMOVE BRAKE PEDAL BRACKET ASSEMBLY (See page 32–9)**
4. **REMOVE BRAKE PEDAL SUB–ASSY**

(a) Remove the clip and master cylinder push rod pin.
(b) Remove the bolt, nut and pedal.
(c) Remove the torsion spring, 2 brake pedal bushes and collar from the pedal sub–assy.
(d) Remove the pedal pad.

5. **INSTALL BRAKE PEDAL SUB–ASSY**

(a) Install the pedal pad.
(b) Install 2 new brake pedal bushes, collar and torsion spring to the pedal.
(c) Install the pedal assy with the bolt and nut.
Torque: 31 N·m (310 kgf·cm, 22 ft·lbf)
(d) Install the master cylinder push rod pin and clip.

6. **INSTALL BRAKE PEDAL BRACKET ASSEMBLY (See page 32–9)**
7. **INSTALL BRAKE MASTER LESS RESERVOIR TANK CYLINDER SUB–ASSY (See page 32–10)**
8. **INSTALL INSTRUMENT PANEL ASSY (See page 71–11, 71–17)**
9. **CHECK AND ADJUST BRAKE PEDAL HEIGHT (See page 32–7)**
10. **CHECK PEDAL FREE PLAY (See page 32–7)**
11. **CHECK PEDAL RESERVE DISTANCE (See page 32–7)**