SPEED SENSOR FRONT LH

320UA-01

REPLACEMENT

1. **REMOVE FRONT WHEEL**
2. **REMOVE SPEED SENSOR FRONT LH**

(a) Disconnect the speed sensor connector.
(b) Remove the bolts from the frame, knuckle and upper arm.
(c) Remove the bolt and front speed sensor from the axle hub.

3. **INSTALL SPEED SENSOR FRONT LH**

(a) Install the front speed sensor to the axle hub with the bolt.
Torque: 8.0 N·m (82 kgf·cm, 71 in.·lbf)
(b) Install each bolt to the frame, knuckle and upper arm.
Torque: 19 N·m (194 kgf·cm, 14 ft·lbf)
(c) Connect the speed sensor connector.

4. **INSTALL FRONT WHEEL**
5. **CHECK ABS SPEED SENSOR SIGNAL (See page 05–195)**