SPEED SENSOR REAR LH

320UB–01

REPLACEMENT

1. REMOVE REAR TIRE

2. REMOVE REAR DRUM BRAKE (See page 32–52)

3. REMOVE SPEED SENSOR REAR LH

(a) Remove each clamp bolt from the differential carrier.

(b) Disconnect the sensor connector.

(c) Remove the bolt and speed sensor from the axle hub.

NOTICE:

Be careful that any foreign matter should not stick to the sensor tip.

4. INSTALL SPEED SENSOR REAR LH

(a) Install the speed sensor to the axle hub with the bolt.

Torque: 8.0 N·m (82 kgf·cm, 71 in.·lbf)

(b) Connect the sensor connector.

(c) Install each clamp bolt to the differential carrier.

Torque: 19 N·m (194 kgf·cm, 14 ft·lbf)

5. INSTALL REAR DRUM BRAKE (See page 32–52)

6. INSTALL REAR TIRE

7. CHECK ABS SENSOR SIGNAL (See page 05–195)