650EE–03

PROBLEM SYMPTOMS TABLE

1. HEADLAMP AND TAIL LAMP

Symptom	Suspected Area	See Page
Only one headlamp comes on.	1. Bulb 2. HEAD (LH) fuse HEAD (RH) fuse 3. Wire harness	– – – –
LO–beam does not operate on both sides.	1. Headlamp dimmer switch 2. Headlamp (H–LP) relay 3. Wire harness	65–6 65–6 –
LO–beam does not operate on either side.	1. Bulb 2. Wire harness	– –
HI–beam does not operate on both sides.	1. Headlamp dimmer switch 2. Wire harness	65–6 –
HI–beam does not operate on either side.	1. Bulb 2. Wire harness	– –
Flash does not operate.	1. Headlamp dimmer switch 2. Wire harness	65–6 –
Headlamp is dark.	1. Bulb 2. Wire harness	– –
Only one tail lamp comes on.	1. Bulb 2. Wire harness	– –
Tail lamp does not come on (Headlamp is normal).	1. TAIL fuse 2. Tail lamp (TAIL) relay 3. Light control switch No. 1 4. Parking lamp switch (w / Parking lamp) 5. Wire harness	– 65–6 65–6 65–6 –
Tail lamp does not come on (Headlamp does not light up).	1. Light control switch No. 1 2. Wire harness	65–6 –
Headlamp beam level control system does not operate on both sides.	1. TAIL fuse 2. Tail lamp (TAIL) relay 3. Headlamp leveling switch 4. Headlamp 5. Wire harness	– 65–6 65–6 – –
Headlamp beam level control system does not operate on either side.	1. Headlamp leveling switch 2. Headlamp 3. Wire harness	65–6 – –
Headlamp beam level control system operates abnormally on both sides.	1. Headlamp leveling switch 2. Headlamp 3. Wire harness	65–6 – –
Headlamp beam level control system operates abnormally on either side.	1. Headlamp leveling switch 2. Headlamp 3. Wire harness	65–6 – –

2. FOG LAMP SYSTEM

Symptom	Suspected Area	See Page
Fog lamp does not light up with light control switch in HEAD (Headlamp is normal).	1. FR FOG fuse 2. Fog lamp (FOG) relay 3. Fog lamp switch 4. Wire harness	– 65–6 65–6 –
Only one fog lamp lights up.	1. Bulb 2. Wire harness	– –

3. TURN SIGNAL AND HAZARD WARNING SYSTEM

Symptom	Suspected Area	See Page
Hazard warning lamp and turn signal lamp do not light up.	1. HAZARD fuse 2. Turn signal flasher relay 3. Wire harness	– 65–4 –
Hazard warning lamps do not light up. (Turn signal is normal)	1. Hazard warning signal switch 2. Wire harness	65–6 –
Turn signal lights do not light up (Hazard warning lamp is normal)	1. Turn signal switch 2. Wire harness	65–6 –
Turn signal does not light up on either side.	1. Turn signal switch 2. Wire harness	65–6 –
Only one bulb lights up.	1. Bulb 2. Wire harness	– –

4. STOP LAMP SYSTEM

Symptom	Suspected Area	See Page
Stop lamp does not light up.	1. STOP fuse 2. Stop lamp switch 3. Wire harness	– 65–6 –
Stop lamp remains on.	1. Stop lamp switch 2. Wire harness	65–6 –
Only one bulb lights up.	1. Bulb 2. Wire harness	– –

5. BACK–UP LAMP SYSTEM

Symptom	Suspected Area	See Page
Back–up lamp does not light up.	1. ECU–IG fuse 2. Back–up lamp switch 3. Wire harness	– 65–6 –
Back–up lamp remains on.	1. Back–up lamp switch 2. Wire harness	65–6 –
Only one bulb lights up.	1. Bulb 2. Wire harness	– –

6. ROOM LAMP SYSTEM

Symptom	Suspected Area	See Page
Room lamp does not light up.	1. DOME fuse 2. Inner rear view mirror 3. Wire harness	– 65–6 –