WIPER AND WASHER SYSTEM

66066–03

PROBLEM SYMPTOMS TABLE

1. WIPER AND WASHER SYSTEM

Symptom	Suspected Area	See Page
Front wipers and washers do not operate.	1. WIP fuse 2. Ignition relay No.2 (IG1–2 relay) (15B–FTE and S05C–TB) 3. Windshield wiper switch assy 4. Wire harness	– 66–3 66–3 –
Front wipers do not operate at LO or HI.	1. Windshield wiper switch assy 2. Front wiper motor & bracket assy 3. Wire harness	66–3 66–3 –
Front wipers do not operate at INT.	1. Windshield wiper switch assy 2. Front wiper motor & bracket assy 3. Wire harness	66–3 66–3 –
Front washer motor does not operate.	1. WIP fuse 2. Windshield wiper switch assy 3. Washer motor 4. Wire harness	– 66–3 66–3 –
Front wipers do not operate when washer switch is ON.	1. Windshield wiper switch assy 2. Front wiper motor & bracket assy 3. Wire harness	66–3 66–3 –
When wiper switch is OFF, wiper blade does not retract or retract position is wrong. *	1. Front wiper motor	66–3

*: Inspect the wiper arm and blade set position.