700R6–01

ON–VEHICLE INSPECTION

1. INSPECT POWER WINDOW

(a) Check the basic function (manual operation function).
  (1) Turn the ignition switch ON.
  (2) Check that the door glass will rise when operating the power window regulator master switch to UP side, and the door glass will go down when operating it to DOWN side.
  (3) Check that the door glass will rise when operating the power window regulator switch of each door to UP side, and the door glass will go down when operating it to DOWN side.
  (4) Check that the door glass other than the driver's seat will not operate when locking the window locking switch.

2. CHECK AUTOMATIC OPERATION FUNCTION

(a) Check the basic function.
  (1) Turn the ignition switch ON.
  (2) Check that it operates AUTO DOWN and the door glass will be fully open when operating the master switch of the power window regulator for the driver's seat to DOWN side by double sifting.
  (3) Check that it operates AUTO UP and the door glass will be fully close when operating the master switch of the power window regulator for the driver's seat to UP side by double sifting.
  (4) Check that the door glass will stop during the AUTO DOWN operation, when operating the master switch of the power window regulator to UP side.
  (5) Check that the door glass will stop during the AUTO UP operation, the door glass will stop when operating the power window switch to DOWN side (However, when continuing the UP and DOWN operations, it will transfer to the manual operation).