700R7–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
”One touch power window system” does not operate	1. Power Window Master Switch 2. Power Window Motor (driver’s side)	70–5 70–5
Power window does not operate (driver’s side)	1. DOOR Fuse (instrument panel J/B) 2. Power Main Fuse (instrument panel J/B) 3. Power Ignition Relay (instrument panel J/B) 4. Power Window Master Switch 5. Power Window Motor (driver’s side) 6. Wire Harness	68–1 68–1 68–1 70–5 70–5 —
Power window does not operate (each seat)	1. DOOR Fuse (instrument panel J/B) 2. Power Main Fuse (instrument panel J/B) 3. Power Ignition Relay (instrument panel J/B) 4. Power Window Switch 5. Power Window Motor 6. Wire Harness	68–1 68–1 68–1 70–5 70–5 —
Passenger’s window cannot be operated by wireless operation via master switch	1. Power Window Master Switch 2. Wire Harness	70–5 —