COMBINATION METER

710ES–01

PROBLEM SYMPTOMS TABLE

Illumination:

Symptom	Suspected Area	See Page
All illumination lights do not light up	1. Combination meter assy 2. Wire harness or connector	– –
Only one illumination light does not light up	1. Combination meter assy	–

Warning Lights:

Symptom	Suspected Area	See Page
Check Engine warning light does not light up	1. Wire harness or connector 2. ECM 3. Combination meter assy	– – –
Discharge warning light does not light up	1. Wire harness or connector 2. ECM 3. Combination meter assy	– – –
Brake warning light does not light up	1. Wire harness or connector 2. Parking brake switch 3. Brake warning switch 4. Combination meter assy	– 71–5 71–5 –
Fuel Level warning light does not light up	1. Wire harness or connector 2. Fuel level warning switch 3. Combination meter assy	– 71–2 –
Low Oil Pressure warning light does not light up	1. Wire harness or connector 2. Low oil pressure warning switch 3. Combination meter assy	– 71–5 –
Fuel Sediment warning light does not light up	1. Wire harness or connector 2. Level warning switch 3. Combination meter assy	– 71–5 –

Indicator Lights:

Symptom	Suspected Area	See Page
Turn indicator light does not light up	1. Wire harness or connector 2. Turn signal and hazard warning system 3. Combination meter assy	– 65–6 –
High Beam indicator light does not light up	1. Wire harness or connector 2. Headlight dimmer switch 3. Combination meter assy	– 65–6 –

Combination Meter (others):

Symptom	Suspected Area	See Page
Malfunction in ODO/TRIP meter	1. Combination meter assy	–