8002H–03

# REPLACEMENT

HINT:

The installation is in the reverse order of the removal.

**1. DISCONNECT BATTERY NEGATIVE TERMINAL**

**2. REMOVE STEERING COLUMN COVER LWR (See page 50–8)**

**3. REMOVE STEERING COLUMN COVER UPR (See page 50–8)**

HINT:

The tilt steering column is in the lowest position when removing the steering column cover.

**4. REMOVE IGNITION OR STARTER SWITCH ASSY**

(a) Disconnect the connector.

(b) Remove the screw and switch.