STARTING & CHARGING


0226J–01

PREPARATION

SST

	09820–00031	Alternator Rotor Rear Bearing Replacer	STARTER ASSY(W04D–J)

Recommend Tools

	09082–00040	TOYOTA Electrical Tester	STARTER ASSY(W04D–J) GENERATOR ASSY(W04D–J)

Equipment

Dial indicator	
Micrometer	
Plastic hammer	
Press	
Pull scale	Brush spring
Sandpaper	Commutator
Soldering iron	
Torque wrench	
Vernier calipers	