





STARTING & CHARGING


022E6–01

PREPARATION

SST

	09285–76010	Injection Pump Camshaft Bearing Cone Replacer	GENERATOR ASSY
	09286–46011	Injection Pump Spline Shaft Puller	GENERATOR ASSY
	09820–00021	Alternator Rear Bearing Puller	GENERATOR ASSY
	09820–00030	Alternator Rear Bearing Replacer	GENERATOR ASSY
	09820–63010	Alternator Pulley Set Nut Wrench Set	GENERATOR ASSY
	09950–60010	Replacer Set	STARTER ASSY GENERATOR ASSY
	(09951–00260)	Replacer 26	STARTER ASSY
	(09951–00390)	Replacer 39	STARTER ASSY
	(09952–06010)	Adapter	STARTER ASSY
	09950–70010	Handle Set	GENERATOR ASSY

Recomended Tools

	09082–00040	TOYOTA Electrical Tester	STARTER ASSY GENERATOR ASSY

Equipment

Ammeter (A)	
Battery specific gravity gauge	Except maintenance– free battery
Belt tension gauge	
Cylinder indicator	Commutator
Micro meter	Starter clutch
Plastic hammer	
Pull scale	Brush spring
Sandpaper	Commutator
Torque wrench	
Vernier calipers	Commutator, Brush, Rotor (Slip ring)