














DIFFERENTIAL

PREPARATION

023VR–01

SST

	09223–15020	Oil Seal & Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09223–78010	Crankshaft Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09308–10010	Oil Seal Puller	REAR DIFFERENTIAL CARRIER OIL SEAL(SH12) DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09315–00022	Clutch Release Bearing Remover & Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09316–60011	Transmission & Transfer Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	(09316–00011)	Replacer Pipe	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	(09316–00071)	Replacer ”F”	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09504–00011	Differential Side Bearing Adjusting Nut Wrench	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09518–36020	Rear Axle Hub Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09950–00020	Bearing Remover	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09950–00030	Bearing Remover Attachment	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09950–40011	Puller B Set	DIFFERENTIAL CARRIER ASSY REAR(SH12)

	(09957–04010)	Attachment	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09950–60010	Replacer Set	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	(09951–00640)	Replacer 64	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	(09951–00650)	Replacer 65	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	09950–60020	Replacer Set No.2	DIFFERENTIAL CARRIER ASSY REAR(SH12)
	(09951–00680)	Replacer 68	DIFFERENTIAL CARRIER ASSY REAR(SH12)

Equipment

Brass bar	
Chisel	
Dial gauge	
Hammer	
Press	
Snap ring expander	
Torque wrench	
Vernier caliper	
Vise	