



CLUTCH

PREPARATION

023VT–01

SST

	09301–00120	Clutch Guide Tool	CLUTCH UNIT(N04C–TF)
	09303–35011	Input Shaft Front Bearing Puller	CLUTCH UNIT(N04C–TF)
	09304–12012	Input Shaft Front Bearing Replacer	CLUTCH UNIT(N04C–TF)
	09333–00013	Universal Joint Bearing Remover & Replacer	CLUTCH UNIT(N04C–TF)

Equipment

Dial indicator with magnetic base	
Lithium soap base glycol grease	
MP grease	
Snap ring pliers	
Torque wrench	
Vernier calipers	