05DVY–04

CHECK FOR INTERMITTENT PROBLEMS

HINT:

Hand–held tester only:

Inspect the vehicle's ECM using check mode. Intermittent problems are easier to be detected when the ECM is in check mode with the hand–held tester. In check mode, the ECM uses 1 trip detection logic, which has a higher sensitivity to malfunctions than normal mode (default), which uses 2 trip detection logic.

(a) Clear DTCs (see page 05–29).
(b) Change the ECM from normal mode to check mode using the hand–held tester (see page 05–31).
(c) Perform a simulation test (see page 01–17).
(d) Check the connectors and terminals (see page 01–27).
(e) Wiggle the harness and connectors (see page 01–27).