057EO–04

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing the skid control ECU, sensor, wire harness and other electrical components, turn the ignition switch OFF.

Symptom	Suspected Area	See Page
* ABS does not operate	1. Check DTC reconfirming that normal code is output 2. Ignition power source circuit 3. Speed sensor circuit	05–181 05–225 05–206 05–206
* ABS does not operate efficiently	1. Check DTC reconfirming that the normal code is output 2. Speed sensor circuit 3. Stop lamp switch circuit	05–181 05–200 05–206 05–232
* BRAKE ASSIST	1. Master cylinder pressure sensor 2. Vacuum sensor 3. Stop lamp switch circuit	05–228 05–228 05–232
ABS warning lamp abnormality	1. ABS warning lamp circuit 2. Skid control ECU assy 3. Combination meter and power source	05–250 01–27 –
* DTC check cannot be performed	1. ABS warning lamp circuit 2. Tc terminal circuit	05–250 05–261
Speed sensor signal check cannot be performed	1. TS terminal circuit 2. Skid control ECU assy	05–263 01–27

HINT:

*: Only replace the skid control ECU assy if all the suspected areas are functioning normally but the problem still occurs.