05BBI–02

DIAGNOSTIC TROUBLE CODE CHART

HINT:
If a malfunction code is displayed during the DTC check, check the circuit indicated by the DTC.
For details of each code, see the page for the respective ”DTC No.” in the DTC chart.

DTC No. (See Page)	Detection Item	Trouble Area
C1382/112 (05–281)	Malfunction in Clutch Stroke Sensor	• Clutch pedal stroke sensor • Skid control ECU • Wire harness
C1383/111 (05–284)	Malfunction in Vehicle Speed Sensor	• Vehicle speed sensor • Skid control ECU • Wire harness
C1384/113 (05–286)	Malfunction in Neutral Switch	• Neutral position switch • Skid control ECU • Wire harness
C1386/116 (05–288)	Malfunction in ES Starting Operation/Release Switch	• ES start switch • Skid control ECU • Wire harness
C1387/115 (05–291)	Malfunction in ES Starting Release Timing Switch	• ES start switch • Skid control ECU • Wire harness
C1388/117 (05–294)	Malfunction in ES Starting Initialization	Skid control ECU
C1389/118 (05–295)	Malfunction in Tachometer Sensor	• ECM • Skid control ECU • Combination meter • Wire harness
C1390/42 (05–298)	Malfunction in Battery Power Supply Voltage	• ECU+B fuse • Skid control ECU • Wire harness