FUEL SYSTEM (N04C–TF)

1114D–01

PRECAUTION

CAUTION:

- **Before working on the fuel system, disconnect the negative (–) terminal cable from the battery.**
- **Do not smoke or be near an open flame when working on the fuel system.**
- **Keep fuel away from rubber or leather parts.**
- **Cover the disconnected fuel system parts with a vinyl or a plastic bag to prevent any damage and dirt.**
- **Each injector assembly has unique fuel injecting characteristics. If the injectors need to be removed, be sure to remember where each injector's previous location was and reinstall them accordingly.**

1. DISCHARGE FUEL SYSTEM PRESSURE

CAUTION:

- **Do not disconnect any part of the fuel system until you have discharged the fuel system pressure.**
- **Even after discharging the fuel pressure, place a shop rag over fittings as you separate them to reduce risk of fuel spray on yourself or in the engine compartment.**

2. CHECK FOR FUEL LEAKS

(a) Check that there are no fuel leaks after doing maintenance anywhere on the fuel system (see page 11–2).