CHARGING SYSTEM (N04C–TF)

190YN–01

PRECAUTION

CAUTION:

- **Check that the battery cables are connected to the correct terminals.**
- **Disconnect the battery cables before the battery is quickly charged.**
- **Do not perform tests with a high–voltage insulation resistance tester.**
- **Never disconnect the battery while the engine is running.**
- **Check that the charging cable is tightened on terminal B of the generator and the fuse box.**
- **Do not check whether the generator generates or not by connecting terminal F to another terminal.**