F RELAY LOCATIONS

: J/B RH	Right Side of the Instrument Panel (See Page 21)

