F RELAY LOCATIONS

Junction Connector (CAN LH No.2)	LHD : Left Kick Panel (See Page 21)
	RHD : Left Side of the Instrument Panel (See Page 21)

