





A37 Stop Lamp SW (GND) W–B (*31)
A39 Headlight Leveling ECU Assembly (E1) W–B (*31)
A34 Stop Lamp Control Relay (GND) W–B (*32)
A31 Stop Lamp Control Relay (GND) W–B (*16)
A10 Brake Fluid Level Warning SW (E) W–B
B8 Engine Hood Courtesy SW (E) W–B 9 BA3 W–B
PTC NO. 1 Relay (–S) 2 W–B
PTC NO. 2 Relay (–S) 2 W–B
PTC NO. 3 Relay (–S) 2 W–B
A26 Headlamp Cleaner Control Relay (E) W–B
A19 Wireless Door Lock Buzzer (E) W–B
A38 Brake Pedal Load Sensing SW (FSW–) W–B (RHD *31)
A8 Windshield Wiper Motor (E) W–B
A23 Seat Belt Control ECU (PGND) W–B
A14 PTC Heater (E) W–B
(E) W
W–B
1 (–S) ST Relay
1 (E) DEF Relay
1 (–S) IG2 Relay
1 (E) EFI MAIN Relay
1 (E) A/F Relay
(FSW–) A24 Brake Pedal Load Sensing SW W–B (LHD *30) W–B (RHD *30)
(FSW–) A40 Brake Pedal Load Sensing SW W–B (LHD *31)
(E1) A28 Headlamp Swivel ECU W–B
W–B (*4) 10 DA2 W–B (*4) (SOL–) D40 A/C Compressor
(EC) A7 Engine ECU W–B
(GND1) A35 Skid Control ECU with Actuator W–B (*25 *1)
(GND2) W–B (*25 *1)
(GND1) A9 Skid Control ECU with Actuator W–B (*1)
(GND2) W–B (*1)
(GND1) A22 Skid Control ECU with Actuator W–B (*2)
(GND2) W–B (*2)
(PGND) A21 Power Steering ECU W
A1
A2
A3
A4
A5




∗ 1 : w/ VSC
∗ 2 : w/o VSC
∗ 3 : 2GR–FE
∗ 4 : 2AZ–FE
∗ 5 : Halogen Type
∗ 6 : RHD 2AZ–FE Except Towing Package
∗ 7 : 2AZ–FE Towing Package
∗16 : Before Apr. 2012 Production
∗25 : From Sep. 2014 Production
∗30 : Before May 2016 Production
∗31 : From May 2016 Production
∗32 : From Apr. 2012 Production until May 2016 Production
∗35 : HID Type, Halogen Type
∗36 : Headlight LED Type
∗39 : w/ Daytime Running Light



G15 DLC3 (SG)
D40 A/C Compressor (SOL–)
D69 A/C Compressor (SOL–)
D1 Engine ECU (E02) (E04) (E05)
G135 Spiral Cable (ECC)
G10 Spiral Cable (ECC)
D2 Engine ECU (E1) (ME01) (E01) (E02) (E03) (E04)
AG3
DA2
AG1
D1
D2
D3
D4
(GND) D16 Ignition Coil (No. 1)
(GND) D17 Ignition Coil (No. 2)
(GND) D18 Ignition Coil (No. 3)
(GND) D19 Ignition Coil (No. 4)
(GND) D20 Ignition Coil (No. 5)
(GND) D21 Ignition Coil (No. 6)
(GND) D26 Ignition Coil (No. 1)
(GND) D27 Ignition Coil (No. 2)
(GND) D28 Ignition Coil (No. 3)
(GND) D29 Ignition Coil (No. 4)
(ME01) D1 Engine ECU
(E03)
(E01)
(E1)
(E01) D5 Transmission Control ECU
(E1)
(Shielded)
BR
W
W–B
∗3 : 2GR–FE
∗4 : 2AZ–FE
∗5 : Halogen Type
∗8 : w/ Power Switch
∗14 : Before Jun. 2010 Production
∗15 : From Jun. 2010 Production
∗18 : Before Apr. 2013 Production
∗19 : From Apr. 2013 Production
∗21 : w/ Ion Generator
∗22 : w/o Ion Generator
∗23 : LHD, RHD Before Apr. 2013 Production
∗44 : Before Aug. 2017 Production
∗45 : From Aug. 2017 Production



(Shielded)
W–B
F14
Parking Assist ECU
(GND1)
F15(C)
Junction
Connector
FG2
Main Body ECU
(GND2)
4A
G65
Junction Connector
IG1
G13
Windshield Wiper
SW Assembly
(EW)
G32
Steering Lock ECU
(GND)
G33
Cigarette Lighter
(E)
G107
Power Outlet
Socket Assembly No. 1
G1
G1
Radio Receiver
Assembly
(GND)
F13
Navigation Receiver
Assembly
GF1
G28
Combination Meter
(EP)
G3
I9
Junction Connector
gl1
g2
Electrical Key
Oscillator
(Front Door RH)
I11
Outer Rear View
Mirror (RH)
(HR–)
(E)
I13
Outer Rear View
Mirror (RH)
I2
Outer Rear View
Mirror (RH)
I14
Power Window
Master SW
I12
Power Window SW
(Front RH)
I3
Power Window
Master SW
I4
Power Window SW
(Front RH)
I5
Power Window ECU
(Front RH)
I6
Door Lock Assembly
(Front RH)
BR
W–B
W–B(RHD)
W–B(LHD)
(∗5)
(∗8)
(∗15)
(∗15 ∗22)
(∗19 ∗21)
(∗14)
(∗18 ∗8)
(∗19 ∗8)
(∗23)
(RHD ∗19)
(LHD ∗19)
(RHD ∗18)
(LHD ∗18)





∗ 1 : w/ VSC
∗ 5 : Halogen Type
∗ 8 : w/ Power Switch
∗ 9 : w/o Power Switch
∗14 : Before Jun. 2010 Production
∗15 : From Jun. 2010 Production
∗16 : Before Apr. 2012 Production
∗17 : From Apr. 2012 Production
∗18 : Before Apr. 2013 Production
∗19 : From Apr. 2013 Production
∗21 : w/ Ion Generator
∗22 : w/o Ion Generator
∗26 : Before Oct. 2015 Production
∗27 : From Oct. 2015 Production until May 2016 Production
∗28 : Taiwan
∗29 : Except Taiwan
∗30 : Before May 2016 Production
∗31 : From May 2016 Production




G36
Headlamp Leveling SW
(E)
W–B
(LHD)
9
RJ
12
RJ
W–B
(LHD ∗30)
(ILL–)
G94
Seat Heater
Switch LH
G40
Gateway ECU
(GND)
W–B
(LHD ∗14)
12
RH
11
RJ
W–B
(LHD ∗30)
(E)
W–B
(LHD ∗31)
(ILL–)
G113
Seat Heater
Switch LH
W–B
(LHD ∗31)
(E)
G108
Clearance Warning ECU
(E)
W–B
(∗27 ∗28, LHD ∗31)
G23
Clearance Warning ECU
(E)
W–B
(LHD ∗26, LHD ∗27 ∗29)
11
RE
12
RL
W–B
(LHD)
(ILL–)
G35
Outer Mirror SW
G24
Clearance Warning
Indicator
(E)
W–B
(LHD)
12
RE
11
RL
W–B
(LHD)
(E)
G9
Transmission
Control SW
(E)
W–B
(LHD)
8
RJ
12
RF
BR
(LHD ∗19 ∗1)
(E)
G101
VSC Off Switch
G44
Power Slide Door
Main SW
(E)
W–B
(LHD ∗30)
11
RC
11
RF
W–B
(LHD ∗19 ∗1)
(ILL–)
(ILL–)
W–B
(LHD ∗30)
12
RC
G114
Power Slide Door
Main SW
(E)
W–B
(LHD ∗31)
(ILL–)
W–B
(LHD ∗31)
G15
DLC3
(CG)
W–B
(LHD)
12
RG
9
4A
W–B
(E2)
G19
Airbag Sensor
Assembly Center
W–B
(LHD)
12
RA
LH–IG Relay 1
W–B
(LHD ∗5)
12
RI
10
RJ
W–B
(LHD)
5
4A
LH–IG Relay 2
W–B
(RHD ∗5)
W–B
(RHD)
13 AG6 (LHD)
17 AG6 (RHD ∗18)
1 AG11 (RHD ∗19)
W–B(LHD)
W–B(RHD)
W–B(RHD)
W–B(LHD)
W–B(RHD ∗5)
W–B(LHD)
W–B(RHD)
W–B(RHD)
W–B
(∗5)
W–B(RHD)



m1
Ion Generator
B
(LHD)
5
Gm1
W–B
(LHD)
12
LC
G47
A/C Amplifier
(GND)
LF
G48
A/C Amplifier
(GND2)
LD
LG
G37
A/C Control Assembly
(Front)
(GND)
LB
LH
G89
Headlamp Cleaner SW
(ILL–)
LA
LI
G8
Headlamp Dimmer
SW Assembly
(LFG)
LE
(EL)
G41
Turn Signal Flasher
(E)
G32
Steering Lock ECU
(SGND)
G46
Trip SW
(E)
(LHD ∗8)
(LHD ∗9)
G20
ID Code Box
G22
Transponder
Key ECU
G7
Key Interlock
Solenoid
G25
Shift Lock
Control ECU
G26
Shift Lock
Control ECU
Q23
A/C Control
Assembly (Rear)
(∗31)
Q21
Television
Display
(∗17)
Q10
Blower SW (Rear)
Q11
A/C Control
Assembly (Rear)
(∗30)
Q16
Power Slide Door
Control SW
Q18
Television
Display
(∗16)
G19
Airbag Sensor
Assembly Center
(E1)
8
5A
9
5D
6
QG1
(ILL–)
∗ 5 : Halogen Type
∗ 8 : w/ Power Switch
∗ 9 : w/o Power Switch
∗14 : Before Jun. 2010 Production
∗16 : Before Apr. 2012 Production
∗17 : From Apr. 2012 Production
∗24 : Before Sep. 2014 Production
∗25 : From Sep. 2014 Production
∗30 : Before May 2016 Production
∗31 : From May 2016 Production
∗40 : w/ Steering Pad SW
∗41 : w/ Tire Pressure Warning System
∗45 : From Aug. 2017 Production
∗46 : From May 2016 Production until Aug. 2017 Production
ACC Relay
P/POINT Relay
RH–IG Relay 1
4
5A
W–B(LHD)
W–B(RHD)
W–B(RHD ∗5)



12
LL
W–B
(LHD)
G116
Junction
Connector
G3
Radio
Receiver Assembly
(SWG)
G
18
(LHD ∗40 ∗31)
G10
Spiral Cable
(EAU)
G
16
17
(LHD ∗40 ∗46)
G135
Spiral Cable
(EAU)
G
(LHD ∗40 ∗45)
W–B
(LHD ∗40 ∗31)
G6
Unlock
Warning SW
(UN–)
W–B
(LHD)
10
LG
12
LI
W–B
(LHD ∗8)
(E)
G29
Certification
ECU
G110
Tire Pressure Warning
Reset Switch
(E)
W–B
(LHD ∗31)
12
LH
11
LC
W–B
(LHD ∗16)
(E)
G16
AFS OFF SW
G28
Combination Meter
(ES)
W–B
(∗41)
11
LJ
10
LC
W–B
(LHD ∗16)
(ILL–)
Q7
Vanity Lamp SW (LH)
(E)
W
(LHD)
7
QG2
(∗30)
7
QG9
(∗31)
W–B
(LHD)
11
LL
W–B
(LHD ∗17)
(E)
G97
AFS OFF
SW
Q1
Vanity Lamp SW (RH)
(E)
W
(LHD)
W–B
(LHD ∗17)
(ILL–)
Q19
Steering Spot
Lamp
(L)
W–B
(LHD ∗24)
8
QG5
W–B
(LHD)
9
LC
W–B
(LHD ∗31)
(ILL–)
G112
Seat Heater
Switch RH
Q22
Steering Spot
Lamp
(L)
W–B
(LHD ∗25)
W–B
(LHD ∗31)
(E)
G68
Junction
Connector
(E)
W–B
(LHD ∗14)
9
LH
9
LB
W–B
(LHD ∗30)
(ILL–)
G93
Seat Heater
Switch RH
G18
Steering Sensor
(ESS)
W–B
(LHD)
12
LJ
10
LB
W–B
(LHD ∗30)
(E)
W–B(LHD)
12
LK
11
LD
W–B
(LHD)
(ILL–)
G51
Ashtray
Illumination
W–B(LHD)
10
LL
W–B(RHD)
W–B(RHD)
W–B(RHD ∗5)
W–B(RHD ∗5)
W–B(RHD)
W–B(RHD)
W–B(RHD)
W–B(RHD)
W–B(RHD)
W–B(RHD)



W–B
(LHD)
W–B
(LHD)
3 3
QG2 QG9
(∗30) (∗31)
W
(E)
Q5
Map Lamp
(Front LH)
(CUT)
Q4
Room Lamp SW
(E)
Q3
Map Lamp
(Front RH)
(E)
Q8
Personal Lamp
(Front LH)
(E)
Q12
Personal Lamp
(Rear LH)
(E)
Q13
Personal Lamp
(Rear RH)
(E)
Q14
Personal Lamp
(Front RH)
n2
Ion Generator
W–B
(RHD ∗31)
n1
Ion Generator
W–B
(RHD ∗32)
5
Gn1
W–B
(RHD ∗17)
m1
Ion Generator
B
(RHD ∗16)
5
Gm1
W–B
(RHD ∗16)
W–B
(RHD)
11 LA
Q7
Vanity Lamp SW (LH)
(E)
W
(RHD)
7 7
QG2 QG9
(∗30) (∗31)
W–B
(RHD)
11 LD
12 LD
Q1
Vanity Lamp SW (RH)
(E)
W
(RHD)
G116
Junction
Connector
G3
Radio Receiver
Assembly
(SWG)
W–B
(RHD ∗31)
18
G10
Spiral Cable
(EAU)
W–B
(RHD ∗46)
16
17
G135
Spiral Cable
(EAU)
W–B
(RHD ∗45)
W–B
(RHD ∗31)
12 LE
12 LG
G45
Power Slide Door
Control SW (LH)
(ILL–)
W–B
(RHD ∗30)
11 LL
11 LJ
(E)
W–B
(RHD ∗30)
12 LL
12 LJ
G15
DLC3
(CG)
W–B
(RHD)
12 LA
G98
Air Purifier
Switch Assembly
(ILL–)
W–B
(RHD ∗32)
11 LC
p1
Hazard Warning
Signal Switch
Assembly
#
(RHD ∗31)
2
Gp1
W–B
(RHD ∗31)
11 LF
12 LC
W–B
(RHD)
12 LB
11 LE
W–B
(RHD ∗5)
12 LK
12 LH
10 LE
(∗24)
(∗25)
11 LH
W–B(RHD)
W–B(RHD ∗5)
W–B(RHD)
W–B(RHD)
W–B(RHD)
W–B(RHD)
W–B(RHD)
G111
Clearance
Warning ECU
G23
Clearance
Warning ECU
G24
Clearance Warning
Indicator
G44
Power Slide Door
Main SW
G134
Power Slide Door
Main SW
G9
Transmission
Control SW
G35
Outer Mirror
SW
G119
Outer Mirror
SW


∗ 5 : Halogen Type
∗ 8 : w/ Power Switch
∗ 9 : w/o Power Switch
∗16 : Before Apr. 2012 Production
∗17 : From Apr. 2012 Production
∗18 : Before Apr. 2013 Production
∗24 : Before Sep. 2014 Production
∗25 : From Sep. 2014 Production
∗30 : Before May 2016 Production
∗31 : From May 2016 Production
∗32 : From Apr. 2012 Production until May 2016 Production
∗45 : From Aug. 2017 Production
∗46 : From May 2016 Production until Aug. 2017 Production


: There is no wire color information.


G36 Headlamp Leveling SW (E)
G89 Headlamp Cleaner SW (ILL–)
G40 Gateway ECU (GND)
G51 Ashtray Illumination (ILL–)
G6 Unlock Warning SW (UN–)
G88 Junction Connector (E)
G18 Steering Sensor (ESS)
G41 Turn Signal Flasher (E)
G46 Trip SW (E)
G25 Shift Lock Control ECU (E)
G26 Shift Lock Control ECU (E)
G47 A/C Amplifier (GND)
W–B(RHD)
W–B(RHD)
W–B(RHD



G120
A/C Control Assembly (Front)
(GND)
G37
A/C Control Assembly (Front)
(GND)
G22
Transponder Key ECU
(GND)
G20
ID Code Box
(GND)
G29
Certification ECU
(E)
Q19
Steering Spot Lamp
(L)
Q22
Steering Spot Lamp
(L)
G32
Steering Lock ECU
(SGND)
W–B
(RHD ∗31)
W–B
(RHD ∗30)
W–B
(RHD ∗9)
W–B
(∗8 RHD)
W–B
(RHD)
W–B
(RHD ∗24)
W–B
(RHD ∗25)
W–B
(RHD)
8
QG5
12
RF
12
RL
10
RH
10
RK
11
RE
10
RM
9
RM
11
RM
12
RM
10
RF
11
RD
9
RG
8
RG
W–B
(RHD ∗30)
W–B
(RHD ∗31)
W–B
(RHD ∗8 ∗30)
W–B
(RHD ∗8 ∗31)
BR
(RHD ∗33 ∗1)
W–B
(RHD ∗33 ∗1)
(ILL–)
(E)
(COM)
(GND)
G94
Seat Heater Switch LH
G113
Seat Heater Switch LH
G93
Seat Heater Switch RH
G112
Seat Heater Switch RH
G31
Power SW
G118
Power SW
G117
Integration Control & Panel Assembly
G101
VSC Off Switch


S11
Back Door
Lock Assembly
(ACT–)
S22
Rear Combination Lamp
(RH)
(E)
S19
Rear Combination Lamp
(LH)
(E)
S7
License Plate Lamp
(RH)
(E)
S10
License Plate Lamp
(LH)
(E)
S9
Back Door Opener SW
(E)
S12
Back Door Lock
Assembly
(E)
S13
Power Back Door
Closer SW
(ILL–)
(E)
W–B
(∗36)
S1
1 oS1
9 SM1
(E) o1
Center Stop Lamp
Assembly
(HLMP) o2
Radio Setting
Condenser
(Center Stop
Lamp)
∗ 1 : w/ VSC
∗ 8 : w/ Power Switch
∗ 9 : w/o Power Switch
∗24 : Before Sep. 2014 Production
∗25 : From Sep. 2014 Production
∗30 : Before May 2016 Production
∗31 : From May 2016 Production
∗33 : From Apr. 2013 Production
until May 2016 Production
∗36 : Headlight LED Type
M24
Power Back Door ECU
(GND)
M2
K9
Slide Door Handle SW
(RH)
(CL–)
K2
K1



M8
Rear Combination Lamp (LH)
(E)
W–B
(*30)
M43
Rear Combination Lamp (LH)
(E)
W–B
(*31)
M26(A), M27(B), M49(C), M50(D)
Junction Connector
M44
Tire Pressure Warning ECU and Receiver
(GND)
W–B
(LHD)
M2
Back Door Warning Buzzer
(BZR–)
W–B
R5
Rear Fog Lamp
(E)
W–B
RM1
M30
Front Seat Inner Belt (LH)
(E)
W–B
(*11 *30, RHD *38 *31)
X12
Front Seat Inner Belt (LH)
(E)
W–B
(*10 *30, RHD *37 *31, LHD *31)
X13
Seat Heater (LH)
(E)
W–B
(*12)
X7
Power Seat SW (Driver' s Seat)
(E)
W–B
(LHD *10)
MX1
ZM3 (*31)
ZM2 (*32)
ZM1 (*16)
Z1
Folding Motor (LH)
Z2
Power Rear No. 2 Seat ECU (LH)
M17
Fuel Suction Pump and Gage Assembly
YM1 (*16)
YM2 (*32)
YM3 (*31)
Y1
Folding Motor (RH)
Y2
Power Rear No. 2 Seat ECU (RH)
M3
L8
Slide Door Lock Release Motor (LH)
(SD–)
L12
Slide Door Closer Relay LH
(E)
LM1
M22
Door Control Relay (LH)
(GND)
M1
L11
Junction Connector
L1
Power Window SW (Rear LH)
L2
Power Window ECU (Rear LH)
L3
Slide Door Lock Remote Control Assembly (LH)
L5
Slide Door Lock Assembly (LH)
(GND2)
L9
Slide Door Handle SW (LH)


∗10 : w/ Power Seat
∗11 : w/o Power Seat
∗12 : w/ Seat Heater
∗16 : Before Apr. 2012 Production
∗30 : Before May 2016 Production
∗31 : From May 2016 Production
∗32 : From Apr. 2012 Production until May 2016 Production
∗37 : w/ Side Airbag
∗38 : w/o Side Airbag
∗43 : w/ Deceleration Sensor
K12 Slide Door Closer Relay RH (E)
N24 Door Control Relay (RH) (GND)
N2 Rear Sunshade Control ECU (E)
N5 Power Outlet Socket Assembly No. 3 (E)
N21 Yaw Rate Sensor (GNDA)
N45 Rear Combination Lamp (RH) (E)
N22 Rear Combination Lamp (RH) (E)
N26 Door Control Receiver (GND)
N30 Front Seat Inner Belt (RH) (E)
W12 Front Seat Inner Belt (RH) (E)
W13 Seat Heater (RH) (E)
W7 Power Seat SW (Driver' s Seat) (E)
KN1
NW1
N1
N3
N2
(Shielded) (∗43)
N29(A), N37(B), N50(C) Junction Connector
K11 Junction Connector
N16 Blower Motor Control (Rear) (GND)
K1 Power Window SW (Rear RH) (GND)
K2 Power Window ECU (Rear RH) (GND)
K3 Slide Door Lock Remote Control Assembly (RH) (E)
K5 Slide Door Lock Assembly (RH) (E1)
K9 Slide Door Handle SW (RH) (GND)
K8 Slide Door Lock Release Motor (RH) (SD–)
N44 Blower Motor (Rear) (–)
N25 Rear Cooler Relay (E)
N14 Blower Motor (Rear) (–)
W–B


F 15
Black




G 61
Gray




G 65
Black




G116
Blue




I 9
Blue




J 9
Blue




K 11
Blue




L 11
Blue




M 26
Blue




M 27
Blue




M 49
Blue




M 50
Blue




N 29
Blue




N 37
Blue




N 50
Blue




4A
White




4D
White




5A
White




5D
White




LA
White




LB
Gray





LC
White





LD
Gray





LE
White



LF
Gray



LG
White



LH
Gray



LI
White



LJ
Gray



LK
White



LL
Gray



LM
White



RA
White



RC
White



RD
Gray



RE
White



RF
Gray



RG
White


RH
Gray



RI
White


RJ
Gray



RK
White


RL
Gray



RM
White




AG1
White




AG3
Gray




AG6
White




AG11
White




BA1
White




BA3
White




BC1
Black




CB2
Black




DA2
White




FG2
White




GF1
Blue




Gm1
White




Gn1
White




Gp1
White




IG1
White




JG1
White




KN1
White




LM1
White




MX1
White




NW1
White




QG1
Black




QG2
Dark Gray




QG5
Black




QG9
Gray




RM1
White




SM1
White




YM1
Black




YM2
Black




YM3
Black




YM3
White Black




ZM1
White




ZM2
White




ZM3
White Black



gI1
Blue



hJ1
Blue



oS1
White

