DOOR LOCK CONTROL SYSTEM

■ DESCRIPTION

- This system is controlled by the Main Body ECU.
- The door lock control system has the following functions:

Function	Outline	Equipped	
		Front Door	Back Door
Manual Lock and Unlock	This function allows an occupant to lock or unlock driver and front passenger doors by pushing the door lock control switch.	○	—
Key-linked lock and unlock function	This function, which is linked with the key cylinder, can lock or unlock all the doors when a lock or unlock operation is effected.	○	○
Key confine prevention function	When the key is present in the ignition key cylinder and the doors are locked while the driver's door is open, all the doors will be automatically unlocked.	○	—
Manual unlock prohibition function	Performing the door lock operation with a transmitter or an ignition key will prohibit unlock operation by the door lock control switch.	○	—
2-step unlock function	This function is provided to unlock the driver's door when the key cylinder is turned the first time, and unlocks the remaining doors when it is turned the second time.	○	—