
■A.D.D. (AUTOMATIC DISCONNECTING DIFFERENTIAL)

1. General

The A.D.D. automatically disconnects the front wheels from the drive train to conserve energy and reduce vibration and noise when 4WD is not being used.

- When the transfer shift lever is shifted from H2 to H4 the front differential automatically connects the front drive shafts.
- When the transfer shift lever is shifted from H4 to H2, the front differential automatically disconnects the front drive shafts.
- The A.D.D. is controlled by the 4WD Control ECU.

▶ System Diagram ◀




A.D.D. Shift Actuator
- Limit Switch
- A.D.D. Shift Motor
- A.D.D. Detection Switch


0240CH16C

CH

2. Layout of Main Components



0240CH57CS




0240CH60CS

3. A.D.D. Shift Actuator


The A.D.D. shift actuator contains the A.D.D. shift motor, limit switch and A.D.D. detection switch. It should not be disassembled.

- The limit switch has two contact point switches (DL1, DL2). Different combinations of the two contact point switches allow detection of the A.D.D. state (ON or OFF).



237CH21

▶ Combinations of Two Contact Point Switches ◀




237CH22

4. System Operation

2WD (H2) → 4WD (H4)


a) When the transfer shift lever is shifted from H2 to H4, the 4WD detection switch ON signal is input into the 4WD Control ECU.
b) The 4WD Control ECU actuates the A.D.D. shift motor.
c) The operation of the A.D.D. shift motor causes the A.D.D. shift fork and sleeve to move toward the left side, thus connecting the front differential and front drive shafts. As result, the torque from the transfer is transmitted to the front wheels.
d) The 4WD Control ECU turns on the 4WD indicator light.



0240CH20C

4WD (H4) → 2WD (H2)

a) When the transfer shift lever is shifted from H4 to H2, the 4WD detection switch OFF signal is input into the 4WD Control ECU.
b) The 4WD Control ECU actuates the A.D.D. shift motor.
c) The operation of the A.D.D. shift motor causes the A.D.D. shift fork and sleeve to move toward the right side, thus disconnecting the front differential and front drive shafts. As result, the torque from the transfer is not transmitted to the front wheels.
d) The 4WD Control ECU turns off the 4WD indicator light.



0240CH21C