NEW FEATURES

■TIRE PRESSURE WARNING SYSTEM

- Tire pressure warning reset switch is newly adopted.
- The current tire inflation pressures are stored in the tire pressure warning ECU and receiver as set pressures when the tire pressure warning reset switch is operated.
- Initialization starts after the tire pressure warning reset switch is pressed and the tire pressure warning light blinks 3 times.
- For details, refer to the 2012 FJ CRUISER Repair Manual (RM18W0U).

▶ Tire Pressure Warning Reset Switch ◀

