■ DIAGNOSIS (Only for the 4-speed automatic transmission models with the 2KD-FTV engine)

If a malfunction occurs in power train-bus CAN communication line, which is established between the engine ECU and transmission control ECU, the transmission control ECU stores DTC (U0001) in its memory. The DTC can be read by connecting an intelligent tester II to DLC3. For details, see Hiace Repair Manual (Pub. No. RM1171E).