■ FUNCTION

1. General

The wireless door lock remote control system in the new model has the following functions:

Function	Outline
All Door Lock Operation	When all the doors are closed, pressing the door lock switch of the transmitter locks all the doors.
All Door Unlock Operation	Pressing the door unlock switch of the transmitter unlocks all the doors.
Automatic Lock Function	If none of the doors are opened within 30 seconds of them being unlocked by the wireless door lock remote control, all the doors are locked again automatically.
Answer Back Operation	The hazard light flashes once when doors are locked, and twice when doors are unlocked to inform the driver that the operation has been completed.
Transmitter Recognition Code Registration Function	• A maximum of 4 types of transmitter recognition codes can be registered in the wireless door control receiver. • When 4 codes are already registered and a new code is registered, it is written over the oldest of the already registered codes.

2. Transmitter Recognition Code Registration Function

Four different codes can be rewritten through the use of the registration function modes described in the table below. The codes are electronically registered (written to and stored) in the EEPROM. For details, refer to Hiace Repair Manual (Pub. No. RM1171E).

Mode	Function
Rewrite Mode	Erases all previously registered codes and registers only the newly received codes. This mode is used whenever a transmitter or the body ECU is replaced.
Add Mode	Adds a newly received code while preserving any previously registered codes. This mode is used when adding a new transmitter. If the number of codes exceeds 4, the oldest registered code is erased first.
Confirm Mode	Confirms how many codes are currently registered. When a new code is added, this mode is used to check how many codes already exist.
Prohibit Mode	Deletes all the registered codes and prohibits the wireless door lock function. This mode is used when the transmitter is lost.