■ MANUAL HEADLIGHT BEAM LEVEL CONTROL SYSTEM

- This system keeps the beam of the headlights adjusted to the appropriate level in accordance with the number (weight) of passengers and volume of luggage.
- This headlight beam level can be adjusted by operating the headlight beam level control switch.
- The new model has a headlight beam level control system with the following equipment:

Destinations	G. C. C. Countries											
Vehicle Type	Van			Commuter			Van		Commuter			
Engine	2TR-FE						2KD-FTV					
Door	5			4			5		4		4	
Roof Type	Standard		High	Standard		High	Standard		Standard		High	
Body Type	Standard		Wide	Standard		Wide	Standard		Standard		Wide	
Grade	DX			DX		GL	DX		DX			GL
Seating Capacity and Rear Side Window	3, panel	6, Glass	3, Panel	15 and 16, Glass		16, Glass	3, Panel	6, Glass	15 and 16, Glass			16, Glass
Transmission	5-Speed Manual											
Setting	Option											

Destinations	Russia & Ukraine	General Countries		
Vehicle Type	Commuter	Commuter		Commuter
Engine	2TR-FE	2TR-FE		
Door	4	4		4
Roof Type	High	High		Middle
Body Type	Wide	Wide		Wide
Grade	GL	GL		GL
Seating Capacity and Rear Side Window	12, Glass	16, Glass	13, Glass	10, Glass
Transmission	5-Speed Manual	5-Speed Manual	4-Speed Automatic	5-Speed Manual
Setting	Option	Option	Standard	Standard

