■5L-E ENGINE

Engine Control System

1) General

The control method of the brake override system has been changed.

System	Function
Brake Override System	The driving torque is restricted when both the accelerator and brake pedals are depressed. (For the Activation Conditions and Inspection Method, refer to the repair manual)