n. Situation: M

The engine switch is touched with an electrical key transmitter sub-assembly when the transmitter battery voltage is low, smart operation is canceled or radio interference occurs.
In this situation, the following control is performed:

Events		Usability function
Warning Condition		Transponder certification result is OK.
Combination Meter Assembly	Buzzer	Sounds once
	Multi-information Display	The following warning message is displayed: ● DEPRESS BRAKE PEDAL AND PUSH ENGINE SWITCH TO START
	Key Operation/Warning Light	Turned on (Green).
Wireless Door Lock Buzzer		—
Warning Stop Condition		The warning is stopped when one of the following condition is met: ● Key is in the vehicle (interior key certification results is OK). ● 10 seconds elapse. ● The engine is running at 500 rpm or more. ● The engine is started. ● The immobiliser system is set and interior certification is stopped or key certification fails.

■ CRANKING HOLD FUNCTION

Once the engine switch is pressed, this function operates the starter until the engine starts, provided that the brake pedal is depressed. This prevents application of the starter for an inadequate length of time and it also prevents the engine from being cranked after it has started. For details, see for 1KD-FTV engine.