■ KEY CANCEL FUNCTION

The following system functions can be deactivated by using the key cancel procedure.

- Entry and Start System Control
- Prevention of Key Confinement
- Warning

A key cancel function is provided to make it possible to disable the entry and start system. Key cancel can be operated when certain operations are performed when the vehicle is under the following conditions:

- Engine switch is off (Lock).
- Driver door is closed.
- Driver door is unlocked.

The operation procedure is as follows:

1. Press the unlock button of the electrical key transmitter sub-assembly.
2. Open the driver door within 5 seconds of completing the step above (driver door: close condition → opened).
3. With the driver door open, press the unlock button of the electrical key transmitter sub-assembly 2 times within 5 seconds of completing the step above.

   NOTICE:

   If the driver door is closed before or while pressing the unlock button, the entry cancel setting mode will end.

4. Finish the step a) to c) within the 30 seconds of completing the step above.

   a) Close and open the driver door twice (driver door: open condition → closed → opened → closed → opened).

   b) With the driver door open, press the unlock button of the electrical key transmitter sub-assembly 2 times.

   NOTICE:

   If the driver door is closed before or while pressing the unlock button, the entry cancel setting mode will end.

   c) Close and open the driver door (driver door: open condition → closed → opened).

5. Close the driver door within 5 seconds of completing the above step.
6. Check that the wireless buzzer sounds twice (short beeps) to confirm that the entry and start system has been canceled.