■ SYSTEM CONTROL

The activating and deactivating conditions for the emergency brake signal are as shown in the following table:

Emergency Brake Signal Operating Conditions	When all of the following conditions are met, the emergency brake signal starts operating: ● Vehicle speed is above 55 km/h (35 mph). ● Driver is depressing the brake pedal. ● Emergency braking is detected from the vehicle deceleration.
Emergency Brake Signal Ending Conditions	When any of the following conditions is met, the emergency brake signal stops operating: ● Driver has released the brake pedal. ● Emergency braking is no longer detected from the vehicle deceleration. ● Driver has pressed the hazard warning signal switch.